

jungla



LODGE
• CAST IRON •
AMERICAN MADE SINCE 1896

TO LIGHT THE SIDE BURNER:
1. Push and turn the Side Burner knob slowly to MAX. The burner should be lit immediately.
2. If burner does not light up, turn the lighting procedure knob off and repeat lighting procedure.
3. If burner does not light up after step 2, turn the knob off, wait 5 minutes, and repeat lighting procedure above or light by match.



9 OUNCE OVAL MINI SERVER

Q275

HMSOV



14 OZ ROUND MINI SERVER

Q275


HMSRD



Perfectos para servir entradas, guarniciones o postres hechos en el horno o en tu churrasquera.



LDP3



**Lodge 16.75 x 9.5 Inch Seasoned Cast Iron
Double Play Reversible Grill/Griddle**

Q575



**10.25 Inch Dual Handle
Cast Iron Grill Pan**

Q350

L8SKL



**12 Inch Dual Handle
Cast Iron Grill Pan**

Q475

L10SKL

3.5" Cast Iron Skillet

Q125
LMS3



6.5" Cast Iron Skillet

Q200
L3SK3



8" Cast Iron Skillet

Q250
L5SK3



CI 10.25 INCH SKILLET

Q350
L8SK3



Cast Iron 10.5" Square Grill Pan

Q375
L8SGP3



12" Cast Iron Skillet

Q450
L10SK3



15" Cast Iron Skillet

Q800
L14SK3



L6SPB41



Essential Skillet Set Q950

- Plancha de hierro fundido sazonada de 10.5 pulgadas
- Sartén de hierro fundido sazonado de 10.25 pulgadas
- Sartén de hierro fundido sazonado de 8 pulgadas
- Soporte de mango de silicona rojo
- 2 rascadores de sartenes
- Salvamantel de silicón

5 Quart Dutch Oven

Q750
L8DOL3



7 Quart Dutch Oven

Q1,250
L10DOL3



3.2 Quart Combo Cooker


Q750
LCC3



Lodge book of Dutch

SOLD OUT

CBLDO





**6 Quart Enamel
Dutch Oven**

Q1,725.00
EC6D43



**3 Quart Enamel
Dutch Oven**


SOLD OUT
EC3D43

**Utiliza tu Dutch Oven en la estufa, horno o
Churrasquera. En ellos puedes sellar, hacer
cocidos, sopas, hornear, dorar y más!**



**Cookbook
The Lodge Cast Iron**

Q350
CBLCI



6.5" Smoker Skillet con tapa

Q350
L3SMSK




Melting pot & Silicone brush

Q275
LMPB21




Ahuma colocando
chips de madeira





**Silicone & Chainmail
Scrubbing Pad, Red, for
International**

Q275
ACM10R41



**CI 6.25 Inch Round
Burger Press**

Q250
L6BP



Lodge Eraser

Q125
A-RUSTY1



Esta es la mejor manera de restaurar el óxido de una sartén Lodge que se ha dejado afuera demasiado tiempo.

Fácil de sostener y usar para eliminar el óxido y el deslustre de la superficie con precisión




Bamboo Scrub Brush

Q100
SCRBRSH



5 niveles



Soporte para sartenes

Q450
L6BP



Set Scraper Combo


Q50



**12" Deep Cast Iron
Seasoned Skillet**

Q600

L10DSK3



Essential Pan Set

Q1,000

L6SPA41



Silicone Handle Holder

Q75 c/u
ASAHH41



Rojo / Negro

Max Temp Handle Holder

Q75
HHMT11



Silicone Assist Holder

Q75 c/u
ASAHH41



Rojo / Negro

Silicone Assist Holder

Q100
ASAHH11




Molde para huevo de silicón

Q50
ASER



Salvamanteles cuadrado de silicona con diseño de sartenes

Q75 c / u
AS7SKT11/41



Salvamanteles de silicón redondo

Q100
ASDHH41



Salvamantel mini de silicón de 5" magnético

Q100
AS7DT41

